

# Spare pads

## Spare pads COLOP



Spare pads



Wire Display



Spare pad



Spare pad



Printer 10  
Mini-Dater S 120  
Mini-Folio S 126  
Mini-Info S 120/W  
Mini-Dater S 160  
L 10, Soft 10

E/10

Mini-Print S 110  
Mini-Folio S 120/13  
Mini-Info-Dater S 120/WD  
Mini-Dater S 120/DD  
Mini-Dater S 120/P  
Mini-Dater S 160/DD

E/12

Printer 15  
L15

E/15

Printer 20  
L 20, Soft 20

E/20

Printer 25

E/25

Printer 30  
L 30, Soft 30

E/30

Printer 35

E/35

Printer 40  
L 40, Soft 40

E/40

Printer 45

E/45

Printer 50

E/50/1

L 50, Soft 50

E/50

Printer 52  
Printer 52-Dater

E/52

Printer 53  
Printer 53-Dater

E/53

Printer 54  
Printer 54-Dater

E/54

Printer (L) 55  
Printer (L) 55-Dater

E/55

Printer (L) 60  
Printer (L) 60-Dater

E/60

Printer R 12

E/R 12

Printer R 17  
Printer R 17-Dater

E/R 17

Printer R 24

E/R 24

Printer R 30  
Printer R 30-Dater

E/R 30

Printer R 40  
Printer R 40-Dater

E/R 40

Printer R 45  
Printer R 45-Dater

E/R 45

Printer R 50  
Printer R 50-Dater

E/R 50

Printer Oval 44

E/OVAL 44

Printer Oval 55  
Printer Oval 55-Dater

E/OVAL 55



Printer S 200  
Printer S 260  
Printer S 220  
Printer S 220/W  
Printer S 226  
Printer S 226/P

E/200

Printer Q 12

E/Q 12

Printer Q 17

E/Q 17

Printer Q 24  
Printer Q 24-Dater

E/Q 24

Printer Q 30  
Printer Q 30-Dater

E/Q 30

Printer Q 43  
Printer Q 43-Dater

E/Q 43

Classic R 2040  
Classic R 2046

E/R 2040

Classic 2100  
Classic 2100/3  
Classic 2100/4  
Classic 2100/W  
Classic 2106  
Classic 2106/P  
Classic 2160

E/2100

Classic 2200  
Classic 2260  
Classic 2300  
Classic 2360  
Classic 2006  
Office S 300  
Office S 360

E/2300

Classic 2400  
Classic 2460  
Classic 2008  
Classic 2010  
Classic 2000/P  
Classic 2000/WD

E/2400

Classic 2600  
Classic 2660  
Classic 2008/P  
Classic 2010/P  
Office S 400  
Office S 600  
Office S 608  
Office S 608/P  
Office S 610  
Office S 610/P  
Office S 660

E/2600

Classic 2800  
Classic 2860

E/2800

Pocket Stamp 20

E/POCKET  
STAMP

Pocket Stamp 30  
Pocket Stamp Oval 30

E/POCKET  
STAMP 30

Pocket Stamp Q 25  
Pocket Stamp R 25

E/POCKET  
STAMP 25

Pocket Stamp R 30

E/POCKET  
STAMP R 30


Pocket Stamp R 40

E/POCKET  
STAMP R 40



# Spare pads

## Two-colour ink pads COLOP



### Spare pads



Mini-Dater S 160 Mini-Dater S 160/L	E/10/2
Printer S 260 Printer S 260/L Printer S 260/RL Printer S 226/P	E/200/2
Printer R 30	E/R 30/2
Printer R 40	E/R 40/2
Printer R 40-Dater	E/R 40 DATER/2
Printer R 40-Dater	E/R 40/1 DATER/2
Printer Q 43-Dater	E/Q 43/2
Printer R 50	E/R 50/2
Printer R 50-Dater	E/R 50 DATER/2
Printer 53-Dater	E/53/2
Printer 54-Dater	E/54/2
Printer 55-Dater	E/55/2



Classic R 2046	E/R 2040/2
Classic 2160 Classic 2160/RL Classic 2106/P	E/2100/2
Classic 2260 Classic 2260/RL Classic 2360 Classic 2006/P Office S 360 Office S 360/RL	E/2300/2
Classic 2460	E/2400/2
Classic 2660 Office S 660	E/2600/2
Classic 2860	E/2800/2



Printer 20	E/20/S6
Printer 30	E/30/S6
Printer 40	E/40/S6
Printer 50	E/50/S6



### Blister Packing

# Spare pads



**Spare pads**



**Spare pads**

## Spare pads for other models



4204	
4254	
4117	E/4204
45510	
45510/PL	

4207	
4470	E/4207

4208	
4258	
4480	
4485	E/4208
5208	
5480	

4200	
4250	
4430	
4431	
4022	
4030	
4031	
4034	
4546	
4548	
5200	
5030	
5430	
5431	
5546	E/4430

4203	
4253	
4440	
4558	
4558/PL	E/4440
4610	
5203	
5440	
5253	

4206	
4256	
4420	
4460	
4465	
5204	
5206	E/4460
5460	
5117	
5558	
5558/PL	
55510	
55510/PL	

4750	
4760	E/4750

4910	
4810	E/4910

4911	
4800	
4820	E/4911
4822	
4846	
4951	

4912	
4952	E/4912
496201-04	

4913	
4953	E/4913

4915	E/4915
------	--------

4916	E/4916
------	--------

4922	E/4922
4923	
4930	E/4923

4924	
4940	
4724	E/4924
4740	

4926	E/4926
------	--------

4927	
4727	E/4927
4957	

4430	
4430/L	
4431	E/4430/2
4435	

4440	E/4440/2
------	----------

4420	
4425	
4460	E/4460/2
4465	
4620	

4750	
4750/L	E/4750/2
4755	